

POLTI CIMEX ERADICATOR+

PROTOCOL FOR USE

HOW TO USE THIS APPLIANCE



WARNING! THIS PROTOCOL DOES NOT REPLACE THE INSTRUCTIONS AND WARNINGS CONTAINED IN THE USER MANUAL AND ON THE APPLIANCE: PLEASE READ THEM BEFORE USE.

- Before starting the treatment, clean - if necessary - the surfaces and fabrics with the most appropriate method for removing dirt and dust.
- If your appliance is equipped with steam adjustment - as it can also be used as a steam cleaner - set it to an average level or, in the presence of preset programs, refer to the instruction manual.
- Heating the dispenser: when the appliance is first switched on, dispense “unusable” steam for about 30 seconds downwards to reach the optimum operating temperature and pressure. After each pause before treating surfaces or fabrics, dispense for a few seconds in the same way.

CHOOSE THE OPERATION YOU WANT TO DO:

DEEP DISINFECTION¹

Objects and surfaces more exposed to frequent and continuous contact (e.g. handles, counters, taps ...)

Dispense steam perpendicular to the surface keeping a maximum **distance of 4 inches** (spacer stand) for **30 consecutive seconds**. The steam will be able to treat an area with a diameter of about 4 inches.



FREQUENT SANITIZING ACTION



Dispense steam with slow and repeated strokes from right to left (or vice versa), or from top to bottom (or vice versa) at about **4 inches per second**.



Refer to the table below for the treatment of different surfaces and fabrics.
 The table indicates, depending on the treatment to be carried out: the use of the stand spacer open (distance 4 inches) or closed (close distance); the use or not of the concentrator accessory (straight or curved).

		STAND / SPACER	CONCENTRATOR ACCESSORY
HARD SURFACES (including glass)		✓	-
UPHOLSTERY (cushions, upholstered chairs, armchairs, mattresses ...)		-	-
FABRICS / CLOTHING¹		-	-
ELECTRICAL APPLIANCES²		✓	-
DRAINS AND GRILLES		-	STRAIGHT
TOILETS / INACCESSIBLE AREAS		-	CURVED

After treatment, wait for the rapid and spontaneous drying of surfaces/fabrics.
 Drying times depend on the environmental conditions (temperature and humidity), on correct use and on the nature and temperature of the surfaces.
 Complete drying with a disposable cloth **only if** absolutely necessary.

HPMED DOES NOT PREVENT, DESTROY, REPEL OR MITIGATE PESTS. HPMED IS A NATURAL DETERGENT WHICH, COMBINED WITH THE STEAM, ELIMINATES THE CHARACTERISTIC SMELL OF BED BUGS.

¹ For fabrics that may be particularly sensitive to heat, avoid concentrating the steam on a fixed point and instead sanitise it with repeated passes. Treat waterproof fabrics as hard surfaces.
² For electrical appliances, remove the plug from the socket before carrying out any operation and wait for the surfaces to dry perfectly.